



Connector at left A-post (wheel housing harness)



C2



1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23	24	25
26	27	28	29	
30	31	32	33	
34	35	36	37	
38	39	40	41	
42	43	44	45	
46	47	48	49	
50	51	52	53	

Black connector C2 (53-pin)
Instrument panel harness - left wheel housing harness

B 230 F REX-I	
1	Starter motor 50 (BL-GN)
2	High beam left (BL-W)
3	Low beam left (GN)
4	Horn + (Y) Windshield wiper motor pos. 1 Headlight wiper motor (not USA/CDN)
5	Windshield wiper motor pos. 2 (GR)
6	Windshield wiper motor pos. 3 (GN-W)
7	Windshield wiper motor pos. 4 (OR)
8	Front foglights (W-SB)
9	Control module REX-I (DI) pos. 5 (BN)
10	-
11	On-board diagnostic (OBD) socket B pos. 5 (GR-OR)
12	On-board diagnostic (OBD) socket A pos. 3 (BL-P)
13	Turn signal, left (GN)
14	Parking light, left (W)
15	-
16	Oil pressure sensor (SB)
17	Horn - (BL-SB)
18	Headlight wiper motor (not USA/CDN) (BL-R) Windshield washer motor
19	Brake fluid level sensor (VO)
20	Engine coolant temperature (ECT) sensor pos. 1 (Y-W)
21	Engine coolant temperature (ECT) sensor pos. 2 (Y-SB)
22	Generator D+ (R)
23	On-board diagnostic (OBD) socket B pos. 6 (BL-W)
24	Service socket (P)
25	On-board diagnostic (OBD) socket A pos. 2 (GN-W)
26	Control module REX-I (DI) pos. 3 (BN-W)
27	Power amplifier/ignition coil REX-I (DI) pos. C (R-W)
28	On-board diagnostic (OBD) socket A pos. 4 (BL) Control module REX-I (DI) pos. 6 Power amplifier/ignition coil REX-I (DI) pos. A
29	Control module REX-I (DI) pos. 17 (Y-GR)
30	-
31	-
32	Washer fluid level sensor (R-SB)
33	Washer motor, tailgate (BL-Y)
34	Door switch (BN-SB)
35	Door switch (W-SB)
36	-
37	-
38	Ambient temperature sensor (GN-Y)
39	Ambient temperature sensor (GN-R)
40	Anti-theft alarm, connector D4 pos. 1 (GR-W)
41	Anti-theft alarm, connector D4 pos. 2 (BN-P)
42	Control module cruise control pos. 10 (BN-GR)
43	Control module cruise control pos. 2 (P-SB)
44	Control module cruise control pos. 7 (BN-OR)
45	Control module cruise control pos. 11 (BL-OR)
46	Control module cruise control pos. 6 (BL-GR)
47	Control module cruise control pos. 4 (OR-W)
48	Control module cruise control pos. 3 (OR-SB)
49	Control module cruise control pos. 13 (GN-OR)
50	-
51	-
52	-
53	-