



Relay location, electrical dist. unit



- | | | | |
|----------|--|----------|---|
| A | Bulb failure warning sensor (7/75) | J | Overload relay 15I (2/6)
(power windows/seat heater) |
| B | Seat belt reminder/key warning (2/5)
(USA, Canada, Korea) | K | Headlight (2/37) |
| C | Windshield wiper intermittent relay (2/4) | L | Central lock (2/7) |
| D | Tailgate wiper intermittent relay (2/16) | M | Fuel injection (2/23) |
| E | Fuel injection (2/13) | N | Overload relay high beam (2/50)
(not USA, Canada) |
| F | Foglights, front (2/2) | O | - |
| G | Headlight flasher (2/36) | P | - |
| H | Exhaust temp. sensor (2/15) (Japan) | R | - |
| I | Overdrive (2/8) | S | - |