

7/17	Mass air flow (MAF) sensor	10/35	Power sunroof lighting switch
7/24	Knock sensor (KS)	10/36	Control panel lighting
7/25	Engine speed (RPM) sensor	10/38	Ashtray lighting, rear
7/26	Pressure sensor, EGR	10/39	Switch lighting, seat heater
7/28	Engine coolant temperature (ECT) sensor, diesel	10/40	Gear selector lighting
7/30	Pressure sensor for charge pressure, turbodiesel	10/43	Right brake light
7/31	Sensor, ABS left front	10/44	Right parking light, rear
7/32	Sensor, ABS right front	10/45	Right parking/tail light
7/33	Sensor, vehicle speed (VSS) and ABS	10/46	Right rear foglight
7/34	Thermoelement, three-way catalytic converter (TWC)	10/47	Bulb, right rear turn signal
7/37	Temperature sensor, EGR	10/48	Right backup (reversing) light
7/38	Low-speed pressure sensor, engine cooling fan	10/50	Left brake light
7/40	High-speed pressure sensor, engine cooling fan	10/51	Left parking light, rear
7/41	High-pressure sensor, A/C	10/52	Left parking/tail light
7/43	Thermostat, driver's seat	10/53	Left rear foglight
7/44	Thermostat, passenger's seat	10/54	Bulb, left rear turn signal
7/47	PTC-resistor, air pre-heating	10/55	Left backup (reversing) light
7/53	Low-pressure sensor, A/C	10/64	Right high beam
7/69	Ambient temperature sensor	10/65	Right extra high beam
7/75	Bulb malfunction indicator	10/66	Right low beam
		10/68	Left high beam
8/1	Operating solenoid, overdrive	10/69	Left extra high beam
8/2	Solenoids, ECC	10/70	Left low beam
8/3	Solenoid coupling, A/C	10/72	Ashtray lighting, front
8/5	Idle air control (IAC) valve	10/74	Indicator light, exhaust gas temperature
8/6-9	Injection valves	10/75	Indicator light, charge pressure, turbodiesel
8/13	Fuel valve, diesel	10/76	Indicator light, diesel preheating
8/15	Hydraulic unit, ABS	10/77	Indicator light, SRS (airbag)
8/17	Converter, EGR	10/78	Indicator light, seat belt
8/24	3-way valve, EGR	10/79	Indicator light, overdrive (auto.)/Gear selection indicator
8/30	Steering wheel module, SRS (airbag)	10/82	Indicator light, ABS
8/31	SRS passenger module	10/83	Indicator light, parking brake
8/33	Igniter for left seat belt tensioner	10/84	Indicator light, brake warning
8/34	Igniter for right seat belt tensioner	10/85	Indicator light, high beam
8/36	Solenoid P-shift lock	10/86	Indicator light, oil pressure
8/42	Solenoid, pulsed secondary air injection (PAIR)	10/87	Indicator light, charge
9/1	Cigar lighter	10/88	Indicator light, bulb failure
9/2	Heated rear window	10/89	Indicator light, rear foglights
9/3	Heater element, driver's seat backrest	10/90	Indicator light, washer fluid level
9/4	Heater element, passenger's seat backrest	10/91	Service indicator
9/5	Heater element, driver's seat cushion	10/93	Indicator light, malfunction indicator lamp (MIL)
9/6	Heater element, passenger's seat cushion	10/94	Indicator light, right turn signal
		10/95	Indicator light, left turn signal
10/1	Left front light	10/96	Instrument lighting
10/2	Right front light	10/103	Switch lighting, heated rear window/door mirrors
10/5	Left front foglight	10/104	Switch lighting
10/6	Right front foglight	10/109	Trailer warning lamp
10/9	Left parking light and front turn signal indicator	10/110	Engine temp. warning lamp
10/10	Right parking light and front turn signal indicator	10/114	Vanity mirror lighting, driver's side
10/11	Left front parking light	10/115	Vanity mirror lighting, passenger's side
10/12	Right front parking light		
10/13	Left front turn signal	11/1-26	Fuses
10/14	Right front turn signal	11/41	Fuse, combined instrument
10/15	Left turn signal repeater (not USA/CDN)		
10/16	Right turn signal repeater (not USA/CDN)	13/2-13/106	Branching points
10/17	Right tail light		
10/18	Left tail light	15/1	Positive terminal
10/19	Extra brake light	15/2	30-rail in el. distribution unit
10/20	Left license plate light	15/9	Fuse-protected 15-rail in el. distribution unit
10/21	Right license plate light		
10/22	Roof light	16/1	Radio
10/24	Trunk light	16/2	Amplifier
10/25	Roof light, load area (5-door)	16/3	Loudspeaker, right front door
10/29	Glove compartment light	16/4	Loudspeaker, left front door
10/30	Door-open warning light, driver's door	16/5	Loudspeaker, right rear door
10/31	Door-open warning light, front passenger's side	16/6	Loudspeaker, left rear door
10/32	Door-open warning light, rear driver's side	16/7	Loudspeaker, instrument panel, right side
10/33	Door-open warning light, rear passenger's side	16/8	Loudspeaker, instrument panel, left side

The component list continues on the next page