

16/9 Antenna
 16/10 Horn 1
 16/11 Horn 2
 16/15 CD-autochanger
 16/16 Antenna booster
 16/17 Loudspeaker, rear parcel shelf, left side
 16/18 Loudspeaker, rear parcel shelf, right side
 17/1 Service data link connector for starter motor operation
 17/11 OBD data link connector
 17/14 Data link connector for diagnosis of power seat

18/5 Transfer box alarm

19/1 Engine coolant temperature (ECT) gauge
 19/2 Rev. counter (RPM gauge)
 19/3 Speedometer
 19/4 Clock
 19/5 Fuel gauge

20/1 Ignition coil
 20/2 Distributor
 20/3-6 Spark plugs
 20/9 Glowplugs
 20/15 Series resistance
 20/18 Cabin fan resistor

31/1 Ground connector right front wing
 31/2 Ground connector left front wing
 31/3 Ground connector body (ground connection, battery-body)
 31/4 Ground connector engine (ground connection, battery-engine)
 31/5 Ground connector for heated rear window (4-door)
 31/6 Ground connector left A-post
 31/10 Ground connector right A-post
 31/11 Ground connector left tail light
 31/12 Ground connector right tail light
 31/13 Ground connector in load area
 31/16 Ground connector at windshield wiper motor
 31/17 Ground connector at power sunroof motor
 31/26 Ground connector, generator
 31/31 Ground connection rail in el. distribution unit
 31/32 Ground connector on engine (power ground)
 31/33 Ground connector on engine (signal ground)
 31/60 Ground connector on engine (diesel)
 31/63 Ground connector at steering column bracket
 31/64 Ground connector engine cooling fan
 31/66 Left seat lift ground terminal
 31/67 Right seat lift ground terminal

C1 Connector, 53-pin
 Instrument panel harness - Door sill harness

C2 Connector, 53-pin
 Instrument panel harness - Left wheel housing harness

C3 Connector, 53-pin
 Instrument panel harness - Right wheel housing harness

C5 Connector, left A-post, 2-pin

C6 Connector, at el. dist. unit, 4-pin

C7 Connector, at steering column, 8-pin

C9 Connector, at centre console, 10-pin

C11 Connector, at el. dist. unit, 4-pin

C15 Connector, at gearbox

C19 Connector, at instrument panel, 2-pin

C20 Connector, under gear lever carrier, 1-pin or 2-pin

C21 Connector, left B-post, 4-pin

C22 Connector, at tailgate, 6-pin (5-door)

C23 Connector, at tailgate, 2-pin (5-door)

C24 Connector, at extra brake light, 2-pin

C25 Connector, tailgate, 2-pin, (5-door)

C27 Connector, tailgate, 1-pin, (5-door)

C29 Connector, at driver's seat, 4-pin

C31 Connector, at passenger's seat, 2-pin

C32 Connector, at driver's seat, 2-pin

C33 Connector, under driver's seat, 2-pin

C34 Connector, under passenger's seat, 2-pin

C36 Connector, under passenger's seat, 2-pin

C37 Connector, under driver's seat, 2-pin

C39 Connector, at driver's seat, 4-pin

C40 Connector, at passenger's seat, 4-pin

C41 Connector, under driver's seat, 6-pin

C42 Connector, under driver's seat, 2-pin

C50 Connector, 8-pin

Left wheel housing harness - Engine harness

C51 Connector, 8-pin

Left wheel housing harness - Engine harness

C54 Connector, 8-pin

Right wheel housing harness - Engine harness

C55 Connector, 8-pin

Right wheel housing harness - Engine harness

C63 Connector, at left headlight, 3-pin

C64 Connector, at right headlight, 3-pin

C65 Connector, driver's door, 6-pin

C66 Connector, passenger's door, 6-pin

C72 Connector, driver's door, 2-pin

C73 Connector, passenger's door, 2-pin

C74 Connector, rear door driver's side, 2-pin

C75 Connector, rear door passenger's side, 2-pin

C79 Connector, driver's door, 4-pin

C84 Connector, driver's door, 2-pin

C85 Connector, rear door driver's side, 2-pin

C86 Connector, passenger's door, 2-pin

C87 Connector, rear door passenger's side, 2-pin

C89 Connector, at sunroof motor, 2-pin

C91 Connector, at el. dist. unit, 2-pin

C92 Connector, behind steering wheel, 2-pin

C93 Connector, left rear wheel housing, 4-pin

C98 Connector, at power antenna, 4-pin

C117 Connector, 2-pin

Left wheel housing harness - Engine harness

C121 Coupling reel, steering wheel, SRS (airbag)

C132 Connector, 8-pin

Left wheel housing harness - Engine harness

C137 Connector, 4-pin

Right wheel housing harness - Engine harness

C139 Connector, at gear selector, 4-pin

C143 Connector, at A-post passenger's side, 24-pin

C144 Connector, at A-post driver's side, 24-pin

C149 Connector, at B-post passenger's side, 11-pin

C150 Connector, at B-post driver's side, 11-pin

C151 Connector at central electronics module, 2-pin

C154 Connector, 3-pin or 1-pin

Right wheel housing harness - engine cooling fan harness

C155 Connector, left A-post, 8-pin

C156 Connector, at firewall, 3-pin

C157 Connector, at el. dist. unit, 4-pin

C158 Connector, at driver's seat, 4-pin

C160 Connector, at instrument panel, 6-pin

C161 Connector, at firewall, 1-pin

C162 Connector, left B-post, 2-pin

C163 Connector, at firewall, 2-pin (diesel)

C166 Connector, at el. dist. unit, 8-pin

C167 Compact Disc changer connector, 2-pin

C300 Connector, at firewall, 4-pin

(for heated oxygen sensor (HO2S))

C301 Connector, at instrument panel for vanity mirror, passenger's side

C302 Connector, at instrument panel for vanity mirror, driver's side

D1 Connector, at instrument panel, 4-pin

D2 Connector, alarm, 8-pin at steering column

D3 Connector, alarm, 4-pin at steering column

D4 Connector, alarm, 2-pin (US/CA), 4-pin (EU/OS) in engine compartment, left front

D5 Connector, towing hook, 10-pin (not USA/CDN)

D7 Connector, ambient temperature sensor, 6-pin

D11 Radio connector, 14-pin

D12 Radio connector, 14-pin