

Branching points

13/16 (Dashboard harness)

On/Off		Color	Remarks
2/7:3	Central Locking relay	BL-R	
6/5:2	Central locking motor passenger side, front (via connector C143:6 at A-post on passenger side)	BL-R	
6/68:2	Central locking motor driver side front (via connector C144:6 at A-post driver side)	BL-R	
6/6:2	Central locking motor passenger side rear (via connector C3:41 Dashboard harness-Right wheelhousing harness and connector C149:2 at B-post passenger side)	BL-R	
13/86	Branching point (via connector C1:41 Dashboard-Rocker panel (door sill) harness) BL-R	BL-R	

13/19 (Dashboard harness)

On/Off		Color	Remarks
11/5:4	Fuse	GN-R	
5/1B:4	Combined instrument	GN-R	
10/30:1	Door edge light, driver door (via connector C144:1 at A-post driver side)	GN-R	
10/31:1	Door edge light passenger side front (via connector C143:1 at A-post on passenger side)	GN-R	
10/33:1	Door edge light passenger side rear (via connector C3:29 Dashboard harness-Right wheelhousing harness and connector C149:3 at B-post passenger side)	GN-R	
3/36	Switch, glove compartment lighting	GN-R	
10/114	Make-up mirror lighting, driver side	GN-R	Only USA/CDN

13/22 (Rocker (door sill) panel harness)

On/Off		Color	Remarks
31/11	Ground point left tail light assy	SB	Only 5-door
31/13	Ground point in cargo area	SB	Only 4-door
6/33-2:4	Fuel pump	SB	
6/34:4	Power antenna	SB	Only 4-door
16/16:4	Antenna booster	SB	Only 5-door
10/17:5	Right tail light	SB	Only 4-door
10/18:5	Left tail light	SB	Only 4-door
10/19:2	High-level brake light	SB	Only 4-door
10/25:2	Cargo area dome light	SB	Only 5-door
13/60	Branching point (via connector C22:6 at tailgate and connector C25:2 at tailgate)	SB	Only 5-door
10/22	Dome light (interior lighting) (via connector C21:3 left B-post)	SB	
D5:3	Towing hitch connector	SB	Not USA/CDN