

Branching points

13/25 (Dashboard harness)

On/Off		Color	Remarks
2/37:3	Main lighting relay (via fuse 11/21)	W	
3/59:4	Beam length control	W	
3/70:1	Rheostat setting	W	
5/1B:13	Combined instrument	W	
10/36	Control panel lighting	W	
10/72	Ashtray lighting, front	W	
10/103	Lighting for switch, heated rear window/power door mirrors	W	
10/104	Lighting for light switch	W	
10/20:1	Left display light	W	Only 4-door
10/21:1	Right display light (via connector C1:6 Dashboard-Rocker panel (door sill) harness)	W	
10/20:1	Left display light	W	Only 5-door
10/21:1	Right display light (via connector C1:6 Dashboard-Rocker panel (door sill) harness) connector C22:2 at tailgate and connector C25:1 at tailgate)	W	
10/9:1	Left side marker light (via connector C2:14 Dashboard harness-Left wheelhousing harness)	W	Only 5-door
16/1:A7	Radio	W	Only EU/OS
16/1:A10	Radio	W	Only USA/CDN
4/6:7	Control module, ECC (via connector D1:1 at dashboard)	W	
4/40:11	MCC climate controls (via connector D1:1 at dashboard)	W	
5/3	Outer temperature sensor (via connector D7:2 outer temp. sensor)	W	

13/26 (Dashboard harness)

On/Off		Color	Remarks
5/1B:12	Combined instrument	BL	
3/59:2	Beam length control	BL	
3/70:4	Rheostat setting	BL	
10/36	Control panel lighting	BL	
10/72	Ashtray lighting, front	BL	
10/103	Lighting for switch, heated rear window/power door mirrors	BL	
10/40:2	Gear selector light (via connector C139:3 at gear shift selector)	BL	Automatic transmission only
10/39:2	Lighting, switch for heated seat (via connector C9:6 at center console)	BL	
16/1:A8	Radio	BL	Only EU/OS
16/1:A11	Radio	BL	Only USA/CDN
4/6:16	Control module, ECC (via connector D1:1 at dashboard)	BL	
4/40:13	MCC climate controls (via connector D1:1 at dashboard)	BL	
5/3	Outer temperature sensor (via connector D7:1 outer temp. sensor)	BL	