

Branching points

13/35 (Engine harness)

	On/Off	Color	Remarks
31/32	Engine ground point (power ground)	SB	
2/38:B1	Exhaust Gas Recirculation System (EGR) time relay	SB	Only D24TIC engine
3/50:2	Throttle Position Switch TP	SB	
7/30:2	Pressure Switch Turbo diesel charge pressure	SB	Only D24TIC engine
8/24:2	Exhaust Gas Recirculation 3-way valve	SB	Only D24TIC engine
4/23:17	Control module, LH Jetronic 2,4 MFI (via connector C54:6 Right wheelhousing harness-Engine harness)	SB	
13/62	Branching point (via connector C132:2 Left wheelhousing harness-Engine harness)	SB	Not B200F, B230FB/G EU/OS
4/15:2	Ignition Discharge Module (IDM) EZ-K DI system (via connector C132:2 Left wheelhousing harness-Engine harness)	SB	Only B200F, B230FB/G EU/OS

13/36 (Left wheelhousing harness on B200FT, B230FT/FK)

13/36 (Right wheelhousing harness on B200F, B230FB/FD/G)

	On/Off	Color	Remarks
1/1	Battery	R	Not D24TIC
2/12:2, 4	Relay radio interference suppressor	R	Only B200F, B230FB/FD/G
2/12:4	Relay radio interference suppressor	R	Only B200FT, B230FT/FK
2/23:3	Fuel injection relay (via connector C2:10 Dashboard- Left wheelhousing harness and Fuse 11/1)	R	Only B200FT, B230FT/FK

13/37 (Driver door harness)

	On/Off	Color	Remarks
13/39	Branching point (via connector C144:21 at A-post driver side)	SB	
6/13:3	Power door mirror driver side	SB	
3/16:5	Power window switch, driver door for driver side rear	SB	
3/18:5	Power window switch, driver door for passenger side rear	SB	
3/23:4	Switch power door mirror driver side	SB	
3/24:4	Switch power door mirror passenger side	SB	

13/38 (Driver door harness)

	On/Off	Color	Remarks
11/8	Fuse (via connector C144:20 at A-post driver side)	Y-R	
3/15:4	Power window switch, driver door for driver door	Y-R	
3/17:4	Power window switch driver door for front passenger side	Y-R	
3/16:4	Power window switch, driver door for driver side rear	Y-R	
3/18:4	Power window switch, driver door for passenger side rear	Y-R	
3/22:1	Rear power windows switch	Y-R	