

## 13/39 (Dashboard harness)

	On/Off	Color	Remarks
<b>31/10</b>	<b>Ground point right A-post</b>	<b>SB</b>	
10/115	Vanity mirror lighting passenger side	SB	
10/114	Make-up mirror lighting, driver side	SB	Only USA/CDN
6/14:3	Power door mirror passenger side (via connector C143:21 at A-post passenger side)	SB	
13/37	Branching point (via connector C144:21 at A-post driver side)	SB	
5/3	Outer temperature sensor (via connector D3:4 Alarm and connector D7:4 outer temp. sensor)	SB	
3/70:6	Rheostat setting	SB	
10/104	Lighting for light switch	SB	
10/29	Glove compartment lighting	SB	

## 13/41 (Right wheelhousing harness)

	On/Off	Color	Remarks
<b>2/23</b>	<b>Fuel injection relay (via connector C3:9 Dashboard harness-Right wheelhousing harness)</b>	<b>BL-Y</b>	<b>Not D24TIC</b>
4/23:9	Control module, LH Jetronic 2,4 MFI	BL-Y	Not D24TIC
7/17:5	Mass air flow (MAF) sensor	BL-Y	Only B200FT, B230FT/FK
7/47:1	PTC resistor, pre-heater	BL-Y	Only B200FT, B230FT/FK
2/12:3	Relay radio interference suppressor	GN-R	Only B200F, B230FB/FD/G
8/5:1	IAC idling valve (via connector C54:3 Engine harness-right wheelhousing harness)	BL-Y	Not D24TIC
13/43	Branching point (via connector C55:6 Engine harness-Right wheelhousing)	GN-R	Only B200F, B230FB/FD/G
7/17:5	Mass air flow (MAF) sensor (via connector C50:5 Right wheelhousing-Engine harness and connector C137:2 Engine harness-Right wheelhousing harness)	BL-Y	Only B200F, B230FT/FK

## 13/43 (Engine harness)

	On/Off	Color	Remarks
<b>13/41</b>	<b>Branching point (via connector C55:6 Right wheelhousing harness-Engine harness)</b>	<b>GN-R</b>	<b>Only B200F and B230FB/FD/G</b>
8/5:1	IAC idling valve	GN	Only B200F, B230FB/FD/G
8/6:1-	Injectors	GN	Only B200F, B230FB/FD/G
8/9:1			

## 13/44 (Engine harness)

	On/Off	Color	Remarks
<b>4/23:18</b>	<b>Control module, LH Jetronic 2,4 MFI (via connector C55:7 Right wheelhousing harness-Engine harness)</b>	<b>GR</b>	<b>Not D24TIC</b>
8/6:2-	Injectors	GR	Not D24TIC
8/9:2			