

13/61 (Rocker (door sill) panel harness)

On/Off	Color	Remarks
31/13 Ground point in cargo area	SB	Only 4-door
10/18:5 Left tail light	SB	Only 4-door
10/17:5 Right tail light	SB	Only 4-door
10/20:2 Left display light	SB	Only 4-door
10/21:2 Right display light	SB	Only 4-door
3/78:8 Lock module, trunk (boot)	SB	Only 4-door

13/62 (Left wheelhousing harness)

On/Off	Color	Remarks
31/32 Engine ground point (power ground) (via connector C132:2 Left wheelhousing harness-Engine harness)	SB	Only B200FT, B230FT/FK
4/10:14 Control module EZK (DI) ignition system	SB	Only B200FT, B230FT/FK
4/15:2 Ignition Discharge Module (IDM) EZ-K DI system	SB	Only B200FT, B230FT/FK

13/63 (Right wheelhousing harness)

On/Off	Color	Remarks
31/33 Engine ground point (signal ground)	BN	Not D24TIC
4/23:5, 19, 29 Control module, LH Jetronic 2,4 MFI	SB	Only B200FT, B230FT/FK
4/23:19, 29 Control module, LH Jetronic 2,4 MFI	BN-SB	Only B200FT, B230FT/FK with automatic transmission

13/70 (Engine harness)

On/Off	Color	Remarks
31/33 Engine ground point (signal ground)	BN	Not D24TIC
7/37:2 Temperature sensor, EGR	BN	Not D24TIC, B200F, B230FB/FD/G EU/OS
4/10:20 Control module EZK (DI) ignition system (via connector C51:3 Left wheelhousing harness-Engine harness)	BN	Not D24TIC
7/17:1 Mass air flow (MAF) sensor (via connector C55:5 Right wheelhousing harness-Engine harness)	BN	Only B200FT, B230FT/FK
4/23:5 Control module, LH Jetronic 2,4 MFI (via connector C55:5 Right wheelhousing harness-Engine harness)	BN	Only B200F, B230FB/FD/G
13/63 Branching point (via connector C55:8 Right wheelhousing harness-Engine harness)	BN	Not B230FD with manual transmission
4/23:19 Control module, LH Jetronic 2,4 MFI (via connector C55:8 Right wheelhousing harness-Engine harness)	BN	Only B230FD with manual transmission
7/17:2 Mass air flow (MAF) sensor (via connector C132:4 Left wheelhousing harness-Engine harness)	BN	Only B200F, B230FB/FD/G