

Branching points

13/75 (Dashboard harness)

On/Off	Color	Remarks
4/9:19 SRS crash sensor module (via connector C11:4 at CEM)	R	Only USA/CDN
4/9:28 SRS crash sensor module (via connector C11:4 at CEM)	R	Only EU/OS
4/16:15 ABS control module (via connector C155:3 at left A-post)	R	
5/1C:3 Combined instrument	R	
4/6:20 Control module, ECC (via connector D1:4 at dashboard)	R	
4/40A:8 MCC climate controls (via connector D1:4 at dashboard)	R	
6/26:D+ Generator (via connector C2:22 Dashboard harness-Left wheelhousing harness) and connector C51:4 Left wheelhousing harness-Engine harness)	R	

13/77 (Dashboard harness)

On/Off	Color	Remarks
2/6:3 Overload relay 151 (via fuse 11/23)	R-SB	
11/23 Fuse	R-SB	
3/29:1 Heated passenger seat switch (via connector C9:9 at center console)	R-SB	
3/28:1 Heated driver seat switch (via connector C9:8 at center console)	R-SB	

13/81 (Dashboard harness)

On/Off	Color	Remarks
3/22:2 Rear power windows switch (via connector C144:9 at A-post driver side)	P	
3/19:4 Power window switch driver side rear (via connector C1:53 Dashboard harness-Rocker panel (door sill) and connector C150:5 at B-post driver side)	P	
3/21:4 Power window switch passenger side rear (via connector C3:53 Dashboard harness-Right wheelhousing harness and connector C149:5 at B-post passenger side)	P	

13/82 (Engine harness)

On/Off	Color	Remarks
3/50:1 Throttle Position Switch TP	OR	Not D24TIC
4/10:7 Control module EZK (DI) ignition system (via connector C51:6 Left wheelhousing harness-Engine harness)	OR	Not D24TIC
4/23:2 Control module, LH Jetronic 2,4 MFI (via connector C54:8 Right wheelhousing harness-Engine harness)	OR	Not D24TIC