


# Ignition switch



## Ignition lock

### Inputs

30: two leads from battery

### Outputs


#### Key position:

-	Key withdrawn
0	Off
I	Radio
II	Drive
III	Start

#### Voltage at connection:

P
S,P
X,S,P
X,15,15I,S
15,50,S

## Relay location in engine compartment



- 2/11\* Relay, engine cooling fan (B 200 F, B 230 FB/FD/G)
- 2/11\*\* Relay, engine cooling fan (B 200 FT, B 230 FK/FT)
- 2/12\* Relay, interference suppression (B 200 F, B 230 FB/FD/G)
- 2/12\*\* Relay, interference suppression (B 200 FT, B 230 FK/FT)
- 2/14 Relay, glow plug (D 24 TIC)
- 2/38 Timer relay, exhaust feedback EGR (D 24 TIC)