


Combined instrument



Instrument panel lamps

| | | | | | |
|-------|---------------------------------------|-------|--|--------|--|
| 10/74 | Warning lamp, exhaust gas temperature | 10/82 | Warning lamp, ABS | 10/90 | Warning lamp, washer fluid level |
| 10/75 | Warning lamp, turbo | 10/83 | Warning lamp, parking brake | 10/91 | Service reminder indicator (SRI) |
| 10/76 | Warning lamp, diesel preheat | 10/84 | Warning lamp, brake warning | 10/92 | Warning lamp, trailer |
| 10/77 | Warning lamp, SRS | 10/85 | Warning lamp, high beam | 10/93 | Warning lamp, malfunction indicator lamp (MIL) |
| 10/78 | Warning lamp, seat belts | 10/86 | Warning lamp, oil pressure | 10/94 | Warning lamp, right turn signal |
| 10/79 | Warning lamp, overdrive, automatic | 10/87 | Warning lamp, charging | 10/95 | Warning lamp, left turn signal |
| 10/80 | Warning lamp, overdrive, manual | 10/88 | Warning lamp, bulb malfunction indicator | 10/96 | Instrument panel lighting |
| | | 10/89 | Warning lamp, rear foglight | 10/110 | Warning lamp, coolant level |

Connectors at instruments

| | | | |
|--|---|-----------------------|---|
| A 8-pin connector (8) | D 4-pin connector (3) | 1/1 | Battery |
| 1 Right turn signal (BL-GN) | 1 Speedometer sensor (GN-W) | 3/1 | Ignition lock |
| 2 Reference ground, ground connector A-post (Y-SB) | 2 - | 3/2 | Light switch |
| 3 - | 3 Ground connector, left A-post (BN-SB) | 3/47 | Parking brake switch |
| 4 - | 4 Supply 15+ (BL-R) | 4/4 | Rheostat |
| 5 Control and instrument lighting, input (Y-W) | B 12-pin connector (12) | 4/5 | Safety circuit SRS |
| 6 Ignition coil output 1 or generator output W (R-W) | 1 Control and instrument panel lighting, external connector to rheostat (BN-SB) | 5/1 | Combined instrument |
| 7 Engine coolant temperature (ECT) sensor (BN-GR) | 2 Brake fluid level sensor (GR-W) | 5/3 | Ambient temperature sensor |
| 8 Engine coolant temperature (ECT) sensor (Y-W) | 3 Parking brake switch (BN-W) | 6/33-1 | Fuel level sensor |
| C 18-pin connector anslutning (18) | 4 ABS (GN) | 7/4 | Brake fluid level sensor |
| 1 Supply 30+ (GN-R) | 5 Engine coolant (EC) level sensor (Y) | 7/5 | Washer fluid level sensor |
| 2 Left turn signal (GN) | 6 Seat belt reminder (GN-Y) | 7/6 | Oil pressure sensor |
| 3 Fuel level sensor (GR-W) | 7 Seat belt reminder (GR-Y) | 7/7 | Engine coolant temperature (ECT) sensor |
| 4 Fuel level sensor (BN) | 8 Relay, glowplug pos. A:1 (OR) | 7/73 | Engine coolant (EC) level sensor (B204FT, D24TIC) |
| 5 Rheostat and clock adjustment pos. A:1 (GN-BN) | 9 - | 11/22, 24, 26, 28, 41 | Fuses |
| 6 - | 10 Pressure sensor, turbo diesel (Y-R) | 15/1 | Positive terminal |
| 7 - | 11 - | 15/3 | 30-rail in fusebox |
| 8 - | 12 Collision sensor, SRS pos. 20 (OR-SB) | 19/1 | Temperature gauge |
| 9 Control module, fuel system pos. 22, Control module, ignition system pos. 3 (BL-P) | Collision sensor, SRS pos. 1 (OR-SB) USA/CDN | 19/2 | Tachometer |
| 10 - | E Digital output, cruise control (GN-OR) | 19/3 | Speedometer |
| 11 Relay, temperature warning (W) | Control module, ECC pos.6 (GN-OR) | 19/4 | Clock |
| 12 - | Relay, overdrive AW70-71 pos. 8 (GN-OR) | 19/5 | Fuel gauge |
| 13 Washer fluid level sensor (BL-W) | Control module, fuel system pos. 34 (GN-OR) | 31/1 | Ground connector, right front wing |
| 14 Switch, foglight pos. 5 (VO-W) | L 2-pin connector | 31/2 | Ground connector left front wing |
| 15 Bulb malfunction indicator (Y-SB) | 1 Relay, overdrive pos. 6 (R-W) | 31/6 | Ground connector, left A-post |
| 16 Generator output D+ (R) | 2 Relay overdrive pos. 5 (R-SB) | 31/9 | Ground connector at parking brake |
| 17 Oil pressure sensor (SB) | | C1 | Connector at left A-post |
| 18 High beam (R-W) | | C2 | Connector left A-post |
| | | C3 | Connector right A-post |
| | | C9 | Connector at relay unit |
| | | C50 | Connector at left suspension tower (D24TIC) |
| | | C51 | Connector at left suspension tower (B204FT, B230GT) |
| | | C93 | Connector at left rear wheel housing |
| | | D7 | Connector, ambient temperature sensor, 6-pin |