


Combined instrument, B6304F/G



Instrument panel lamps

10/74	Warning lamp, exhaust gas temperature	10/82	Warning lamp, ABS	10/90	Warning lamp, washer fluid level
10/75	-	10/83	Warning lamp, parking brake	10/91	Service reminder indicator (SRI)
10/76	-	10/84	Warning lamp, brake warning	10/92	Warning lamp, trailer
10/77	Warning lamp, SRS	10/85	Warning lamp, high beam	10/93	Warning lamp, malfunction indicator lamp (MIL)
10/78	Warning lamp, seat belts	10/86	Warning lamp, oil pressure	10/94	Warning lamp, right turn signal
10/79	-	10/87	Warning lamp, charging	10/95	Warning lamp, left turn signal
10/80	-	10/88	Warning lamp, bulb malfunction indicator	10/96	Instrument panel lighting
		10/89	Warning lamp, rear foglight	10/110	Warning lamp, engine coolant

Connectors at instruments

A 8-pin connector (8)	D 4-pin connector (3)	1/1	Battery
1 Right turn signal (BL-GN)	1 Speedometer sensor (GN-W)	3/1	Ignition lock
2 Reference ground, ground connector A-post (Y-SB)	2 -	3/2	Light switch
3 Control module, AW30-43 pos. B:8 (GN-SB)	3 Ground connector, left A-post (BN-SB)	3/47	Parking brake switch
4 -	4 Supply 15+ (BL-R)	4/4	Rheostat
5 Control and instrument lighting, input (Y-W)		4/5	Safety circuit SRS
6 Motronic control module pos. 6 (R-W)	B 12-pin connector (12)	5/1	Combined instrument
7 Engine coolant temperature (ECT) sensor (BN-GR)	1 Control and instrument panel lighting, external connector to rheostat (BN-SB)	5/3	Ambient temperature sensor
8 Engine coolant temperature (ECT) sensor (Y-W)	2 Brake fluid level sensor (GR-W)	6/33-1	Fuel level sensor
	3 Parking brake switch (BN-W)	7/4	Brake fluid level sensor
C 18-pin connector anslutning (18)	4 ABS (GN)	7/5	Washer fluid level sensor
1 Supply 30+ (GN-R)	5 Engine coolant (EC) level sensor (Y)	7/6	Oil pressure sensor
2 Left turn signal (GN)	6 Seat belt reminder (GN-Y)	7/7	Engine coolant temperature (ECT) sensor
3 Fuel level sensor (GR-W)	7 Seat belt reminder (GR-Y)	7/73	Engine coolant (EC) level sensor
4 Fuel level sensor (BN)	8 -	11/22, 24, 26, 28, 41	Fuses
5 Rheostat adjustment pos. A:1 (GN-BN)	9 -	15/1	Positive terminal
6 -	10 -	15/3	30-rail in fusebox
7 -	11 -	19/1	Temperature gauge
8 -	12 Collision sensor, SRS pos. 20 (OR-SB)	19/2	Tachometer
9 Control module, Motronic pos. 15 (OR)	Collision sensor, SRS pos. 1 USA/CDN (OR-SB)	19/3	Speedometer
10 -		19/4	Clock
11 Relay, temperature warning (W)	E Digital output, cruise control (GN-OR)	19/5	Fuel gauge
12 -	Control module, ECC pos. 6 (GN-OR)	31/1	Ground connector, right front wing
13 Washer fluid level sensor (BL-W)	Control module, Motronic pos. 9 (GN-OR)	31/2	Ground connector left front wing
14 Switch, foglight pos. 5 (VO-W)		31/6	Ground connector, left A-post
15 Bulb malfunction indicator front pos. B:7, rear pos. 11 (Y-SB)	L 2-pin connector	31/9	Ground connector at parking brake
16 Generator output D+ (R)	1 -	C1	Connector at left A-post
17 Oil pressure sensor (SB)	2 Relay, transmission pos. B:2 (GN-W)	C2	Connector left A-post
18 High beam (R-W)		C3	Connector right A-post
		C9	Connector at relay unit
		C61	Connector, 8-pin
		C93	Connector at left rear wheel housing
		C131	Connector at left suspension tower
		D7	Connector, ambient temperature sensor, 6-pin