


# Connector right A-post (wheel housing harness)



B6304F/G			D24TIC		
1	Battery +	(Y-BN)			
2	High beam right	(R-W)	High beam right	(R-W)	
3	Low beam right	(GN-W)	Low beam right	(GN-W)	
	Beam width control		Beam width control		
4	Headlight wiper motor right (not USA/CDN)	(Y)	Headlight wiper motor right (not USA/CDN)	(Y)	
5	Relay, engine cooling fan pos. B1	(GN-OR)			
	Low-speed pressure sensor, engine cooling fan pos. 2				
6	Relay, engine cooling fan pos. B2	(Y-BN)			
	High-speed pressure sensor, engine cooling fan pos. 2				
7					
8	Fog lights, auxiliary lights	(W-SB)	Fog lights, auxiliary lights	(W-SB)	
9					
10					
11	Pressure sensor, A/C	(GN-Y)	Pressure sensor, A/C	(GN-Y)	
12	Turn signal, right	(BL-GN)	Turn signal, right	(BL-GN)	
13	Parking light, right	(GR)	Parking light, right	(GR)	
14	ABS control module pos. 29	(GN)			
	ABS hydraulic unit pos. 11				
15	ABS control module pos. 25	(Y-BN)			
16	Engine coolant level sensor pos. 1	(Y)	Engine coolant level sensor pos. 1	(Y)	
17	Headlight wiper motor right (not USA/CDN)	(BL-R)	Headlight wiper motor right (not USA/CDN)	(BL-R)	
18	Pressure sensor, A/C	(GR-OR)	Pressure sensor, A/C	(GR-OR)	
19	ABS control module pos. 1	(BL-R)			
20	Beam width control right actuator, pos. 2	(GR-R)	Beam width control right actuator, pos. 2	(GR-R)	
21	Control module ABS pos. 7	(GN-W)	Washer fluid level sensor	(BL-W)	
22	Control module ABS pos. 9	(BN-W)			
23	Control module ABS pos. 31	(BL-P)	Tailgate washer motor	(BL-Y)	
24	Control module ABS pos. 15	(P)			
25	Ground connection right A-post	(Y-SB)			
26					
27	Warning light, front door	(BL-SB)	Warning light, front door	(BL-SB)	
	Warning light, rear door		Warning light, rear door		
28	Warning light, front door	(W-SB)	Warning light, front door	(W-SB)	
29	Warning lights, right rear door	(GN-R)	Warning lights, right rear door	(GN-R)	
	Vanity mirror light, right		Vanity mirror light, right		
30	Turn signal side repeater (not USA/CDN)	(BL-GN)	Turn signal side repeater (not USA/CDN)	(BL-GN)	
31	Rear loudspeaker +	(Y-SB)	Rear loudspeaker +	(Y-SB)	
32	Rear loudspeaker -	(GN-SB)	Rear loudspeaker -	(GN-SB)	
33					
34					
35					
36					
37	Ground connector right A-post	(SB)	Ground connector right A-post	(SB)	
38					
39					
40					
41					
42	Power window lift rear, right	(P)	Power window lift rear, right	(P)	
43					
44					
45					
46					
47					
48	Central locking, rear door, left pos. 1	(R-W)	Central locking, rear door, left pos. 1	(R-W)	
49	Central locking, rear door, left pos. 2	(BL-R)	Central locking, rear door, left pos. 2	(BL-R)	
50					
51					
52	Switch, power window lift pos. 3	(BN)	Switch, power window lift pos. 3	(BN)	
53	Switch, power window lift pos. 5	(Y)	Switch, power window lift pos. 5	(Y)	