


Connector, right A-post (wheel housing harness)



B230GT			B204FT		
1	Control module LH (MFI) pos. 30	(P)	Control module LH (MFI) pos. 30	(P)	
2	High beam, right	(R-W)	High beam, right	(R-W)	
3	Low beam, right	(GN-W)	Low beam, right	(GN-W)	
	Beam width control	(BN-GN)	Beam width control	(BN)	
4	Headlight wiper motor right (not USA/CDN)	(Y)	Headlight wiper motor right (not USA/CDN)	(Y)	
5	Control module LH (MFI) pos. 35	(BL)	Control module LH (MFI) pos. 35	(BL)	
6	Control module LH (MFI) pos. 34	(GN-OR)	Control module LH (MFI) pos. 34	(GN-OR)	
7	Control module LH (MFI) pos. 20	(Y-SB)	Control module LH (MFI) pos. 20	(Y-SB)	
8	Fog lights, auxiliary lights	(W-SB)	Fog lights, auxiliary lights	(W-SB)	
9	Control module LH (MFI) pos. 9	(BL-Y)	Control module LH (MFI) pos. 9	(BL-Y)	
	Mass air flow (MAF) sensor pos. 5		Mass air flow (MAF) sensor pos. 5		
	IAC valve pos. 1		IAC valve pos. 1		
	PTC resistor pos. 1		PTC resistor pos. 1		
10	Control module LH (MFI) pos. 4	(Y-BN)	Control module LH (MFI) pos. 4	(Y-BN)	
11	Control module LH (MFI) pos. 12	(GN-GR)	Control module LH (MFI) pos. 12	(GN-GR)	
12	Turn signal right	(BL-GN)	Turn signal right	(BL-GN)	
13	Parking light right	(GR)	Parking light right	(GR)	
14	Control module LH (MFI) pos. 22	(BL-P)	Control module LH (MFI) pos. 22	(BL-P)	
15	Control module LH (MFI) pos. 1	(Y-GR)	Control module LH (MFI) pos. 1	(Y-GR)	
16			Engine coolant level sensor	(Y)	
17	Headlight wiper motor right (not USA/CDN)	(BL-R)	Headlight wiper motor right (not USA/CDN)	(BL-R)	
18	Pressure sensor, A/C	(GN-Y)	Pressure sensor, A/C	(GN-Y)	
19	Control module LH (MFI) pos. 21	(R)	Control module LH (MFI) pos. 21	(R)	
20	Beam width control	(GR-R)	Beam width control	(GR-R)	
21	Washer fluid level sensor	(BL-W)	Washer fluid level sensor	(BL-W)	
22	Control module LH (MFI) pos. 15	(W)	Control module LH (MFI) pos. 23	(W)	
23	Washer motor, rear	(BL-Y)	Washer motor, rear	(BL-Y)	
24					
25	Control module LH (MFI) pos. 28	(R-SB)			
26					
27	Warning light, front door right	(BL-SB)	Warning light, front door right	(BL-SB)	
	Warning light, rear door right		Warning light, rear door right		
28	Warning light, front door right	(W-SB)	Warning light, front door right	(W-SB)	
29	Warning lights, rear door light	(GN-R)	Warning lights, rear door light	(GN-R)	
	Vanity mirror light, right		Vanity mirror light, right		
30	Turn signal side repeater	(BL-GN)	Turn signal side repeater	(BL-GN)	
31	Rear loudspeaker +	(Y-BN)	Rear loudspeaker +	(Y-SB)	
32	Rear loudspeaker -	(GN-BN)	Rear loudspeaker -	(R-SB) (GN-SB)	
33					
34					
35					
36	Ground speedometer	(BN-SB)			
37	Ground connector right A-post	(SB)	Ground connector right A-post	(SB)	
38					
39					
40					
41					
42	Power window lift rear, right	(P)	Power window lift rear, right	(P)	
43					
44					
45					
46					
47					
48	Central locking rear door left, pos. 1	(R-W)	Central locking rear door left, pos. 1	(R-W)	
49	Central locking rear door left, pos. 2	(BL-R)	Central locking rear door left, pos. 2	(BL-R)	
50					
51					
52	Switch, power window lift pos. 3, right rear	(BN)	Switch, power window lift pos. 3, right rear	(BN)	
53	Switch, power window lift pos. 5, right rear	(Y)	Switch, power window lift pos. 5, right rear	(Y)	