

7/12	Solar sensor	10/24	Trunk light
7/15	Heated oxygen sensor (HO2S)	10/25	Roof light, load area (5-door)
7/16	Engine coolant temperature (ECT) sensor, fuel/ignition system	10/26	Reading light, left rear
7/17	Mass air flow (MAF) sensor	10/27	Reading light, right rear
7/21	Camshaft position (CMP) sensor	10/29	Glove compartment light
7/22	Engine speed (RPM) sensor	10/30	Door open warning light driver's door
7/23	Knock sensor (KS), rear	10/31	Door open warning light passenger's door
7/24	Knock sensor (KS), front	10/32	Door open warning light driver's side rear
7/25	Impulse sensor	10/33	Door open warning light passenger's side rear
7/26	Pressure sensor, EGR	10/35	Switch lighting, sunroof switch
7/28	Engine coolant temperature (ECT) diesel	10/36	Control panel lighting
7/30	Pressure sensor for charge pressure, turbodiesel	10/37	Cigar lighter illumination
7/31	Sensor ABS left front	10/38	Ashtray illumination, rear
7/32	Sensor ABS right front	10/39	Seat heater switch illumination
7/33	Sensor speedometer and ABS	10/40	Gear selector illumination
7/34	Thermoelement three-way catalytic converter (TWC)	10/43	Right brake light
7/36	Exhaust temperature sensor	10/44	Right parking light rear
7/37	Temperature sensor EGR	10/45	Right parking / tail light
7/38	Low-speed pressure sensor, engine cooling fan	10/46	Right rear foglight
7/40	High-speed pressure sensor, engine cooling fan	10/47	Light, right rear turn signal
7/41	High-pressure sensor, A/C	10/48	Right backup (reversing) light
7/47	PTC-resistor air pre-heating	10/50	Left brake light
7/53	Low-pressure sensor, A/C	10/51	Left parking light, rear
7/54	Throttle position (TP) sensor	10/52	Left parking / tail light
7/69	Ambient temperature sensor	10/53	Left rear foglight
7/73	Engine coolant level sensor	10/54	Lamp left rear turn signal
7/74	Oil temperature sensor AW30-40/43	10/55	Left backup (reversing) light
7/76	Temperature sensor TCU	10/64	Right high beam
8/1	Operating solenoid, overdrive	10/65	Right extra high beam
8/2	Operating solenoids, ECC	10/66	Right low beam
8/3	Solenoid coupling, A/C	10/68	Left high beam
8/5	Idle air control (IAC) valve	10/69	Left extra high beam
8/6-11	Injectors	10/70	Left low beam
8/13	Fuel valve, diesel	10/72	Ashtray illumination, front
8/14	Solenoid valve, overload protector	10/74	Indicator light exhaust temperature
8/15	Hydraulic unit ABS	10/75	Indicator light charge pressure, turbodiesel
8/17	Converter, EGR	10/76	Indicator light diesel preheating
8/24	3-way valve EGR	10/77	Indicator light SRS
8/28	Turbo control valve	10/78	Indicator light seat belt
8/30	Steering wheel module SRS	10/79	Indicator light overdrive (auto.)/gear change indicator
8/31	Passenger module SRS	10/80	Indicator light overdrive (man.)
8/33	Igniter, seat belt pre-tensioner, left side	10/81	Indicator light engine coolant level
8/34	Igniter, seat belt pre-tensioner, right side	10/82	Indicator light ABS
8/36	Solenoid P-shift lock	10/83	Indicator light parking brake
8/37	Solenoids AW30-40/43	10/84	Indicator light brake warning
9/1	Cigar lighter	10/85	Indicator light high beam
9/2	Heated rear window	10/86	Indicator light oil pressure
9/3	Heater element driver's seat backrest	10/87	Indicator light charging
9/4	Heater element passenger's seat backrest	10/88	Indicator light bulb failure sensor
9/5	Heater element driver's seat cushion	10/89	Indicator light rear foglights
9/6	Heater element passenger's seat cushion	10/90	Indicator light washer fluid level sensor
10/1	Left front light	10/91	Service indicator
10/2	Right front light	10/92	Indicator light trailer
10/5	Left front foglight	10/93	Indicator light
10/6	Right front foglight		Malfunction Indicator Lamp (MIL)
10/9	Left parking light and front turn signal	10/94	Indicator light right turn signal
10/10	Right parking light and front turn signal	10/95	Indicator light left turn signal
10/11	Left parking light, front	10/96	Instrument lighting
10/12	Right parking light, front	10/114	Vanity mirror light, right side
10/13	Left turn signal front	10/115	Vanity mirror light, left side
10/14	Right turn signal front	10/116	Spare fuse illumination
10/15	Left turn signal side repeater (not USA/CDN)	11/1-35	Fuses
10/16	Right turn signal side repeater (not USA/CDN)	11/41	Fuse, combined instrument
10/17	Right tail light		
10/18	Left tail light		
10/19	Extra brake light		
10/20	Left number plate light		
10/21	Right number plate light		
10/22	Roof light		

The component list continues on the next page