

Cruise control (B230GT, B204FT and D24TIC)

Live connections in different settings of switch 3/4 with ignition switch in position II

3/4	OFF	ON	ON Set speed	RESUME
1		X	X	X
2	X	X	X	X
3			X	X
4			X	

Function diagram
see page 42

