


Cruise control, function (schematic presentation)




Setting speed

Switch set to ON. SET-button pressed and released.
 Speed above 35 km/h (20 mph) and brake and/or
 clutch pedal not pressed.
 (In addition, for automatic transmission,
 gear selector lever not in N-position)

Maintaining set speed

Switch set to ON. Speed above 35 km/h (20 mph)
 and brake and/or clutch pedal not pressed.
 (In addition for automatic transmission,
 gear selector lever not in N-position)



Resuming set speed

Switch set to RESUME.

The vehicle resumes the previously set speed.