


Parking lights, tail lights and number plate lights, 5-door



Ignition key in position 0.
Light switch at parking light position.

Ignition key at II.
Light switch at low/high beam setting.

