


M 46 Overdrive



Engaging overdrive,
Gear lever in 4th gear

Downshift from 4th gear,
overdrive disengages
automatically

Disengaging overdrive,
gear lever in 4th gear

