

Alphabetical index

ABS brake system	134
Ambient temperature gauge	118
Anti-theft alarm, pre-routed wiring	100
Backup (reversing) lights	68
Beam width control	58
Brake light	64, 66
Bulb malfunction indicator	104, 106, 108
Cabin fan, standard heater	156
Central locking	138
Cigar lighter	96
Combined instrument	114
Component list (foldout)	at end of book
Cruise control	30, 32
On-board diagnostic system (OBD)	98
Diesel, pre-heating, overload sensor and EGR (D 24 TIC)	44
Electrical distribution unit, relays, fuses.....	4, 5, 6, 7
Electronic climate control (ECC)	160
Engine cooling fan	28
Exhaust gas temp. sensor (Japan)	162
Foglights	78, 80
Foglights, rear, USA/Canada	84
Glove compartment and vanity mirror lights	70
Ground connections	20
Headlight wash/wipe	90
Heated driver's/passenger's seat	148, 150
Heated rear window and door mirrors with timer relay	142, 144
High and low beams	46, 48, 50, 54, 56
Horn	88
Ignition system	34, 36, 38
Instrument and panel lights	76
Interior lights	72
LH-jetronic 2.4 (MFI)	22, 24
Luggage compartment light	74
Manual climate control (MCC)	158
Overdrive	128, 130
P-Shift lock, automatic transmission	132
Parking, tail and number plate lights	60, 62
Power door mirrors	146
Power seats	152, 154
Power sunroof	140
Power supply	40
Power windows	136
Pre-routed wiring for alarm	100
Radio connections	120, 122, 124, 126
Reduced intensity (DIM-DIP) Great Britain	52
Regina (MFI) (B 230 F)	26
Seat belt reminder	110, 112
Speedometer and odometer	116
SRS Supplemental Restraint System	164, 166
Starter system	42
Tailgate wash/wipe	94
Towing hook, pre-routed wiring	102
Turn signals - hazard warning lights	86
Windshield wash/wipe	92