



31/9




Power seats
Parking brake switch
Heated seats
Seat belt lock, driver's seat


31/13



Fuel primer pump (LH 2.4) (MFI)
Fuel pump (Regina) (MFI)
Tail lights
Number plate lighting
Trunk lighting
Extra brake light
Power antenna
Interior lighting
Reading lamps
Towing hook
CD-autochanger



31/10



Cabin fan
Ground connection rail in electrical distribution unit
Bulb malfunction indicator
Flasher unit
Intermittent relay, wipers
Headlight relay
Power sunroof
Overdrive relay
Central lock motors
Power door mirrors
Power windows
Bypass relay 15I (window lifts/seat heaters)
(Accessories)
Central lock relay
Relay, seat belt reminder
Cigar lighter
Radio
Glove compartment lighting
Separate amplifier, radio
Fuel pump (LH 2.4) (MFI)
Fog light switch
Combined instrument
Fuel gauge
Electronic climate unit ECC
Control module DIM-DIP
Right turn signal side repeater
Bypass relay, high beam
Control lighting
Vanity mirror light
Relay, exhaust gas temp. sensor (Japan)
Relay, P-shift lock
Beam width control
Switch, heated rear window/door mirrors
Switch, power door mirrors
Ambient air temperature gauge
Anti-theft alarm