




# Connector at left A-post (bottom rail harness)

## White connector C1 (53-pin) Instrument panel harness - sill harness



all models		
1	Tail lights	BN-W
2	Tail lights	R
3	Brake light, left	Y-R
4	Brake light, right	Y
5	Backup (reversing) lights	SB
6	License plate lights	W
7	Turn signal, left rear	GN
8	Turn signal, right rear	BL-GN
9	Fuel level sensor/primer pump (pump)	GR-W
10	Heated rear window	Y
11	Sensor, speedometer -	BN-W
12	Sensor, speedometer +	GN-W
13	Door switch, pre-routed interior lighting	W-SB
14	Towing hook pos. 10	BL-GN
15	Rear foglights	GR
16	Fuel level sensor/primer pump (pump)	BN
17	Fuel level sensor/primer pump (pump)	P
18	Extra brake light	Y-SB
19	Tailgate wiper	OR
20	Tailgate wiper	Y-W
21	Power antenna pos. 3	GN-GR
22	-	
23	-	
24	Ground connector, left A-post	BN-GR
25	Towing hook pos. 9	W-SB
26	Towing hook pos. 7	W
27	Towing hook pos. 5	GR
28	Towing hook pos. 6	Y-BN
29	Door-open warning light, left rear Interior lighting Trunk light Power antenna pos. 1	GN-R
30	Interior lighting	BN-SB
31	Connector, tailgate/trunk (anti-theft alarm)	BN-OR
32	-	
33	Loudspeaker rear parcel shelf right side +	P-W
34	Loudspeaker rear parcel shelf right side -	P-SB
35	Loudspeaker left rear door + Loudspeaker rear parcel shelf left side +	BL-P
36	Loudspeaker left rear door - Loudspeaker rear parcel shelf left side -	BN-P
37	-	
38	Central locking, rear door Central locking, tailgate/trunk	R-W
39	-	
40	-	
41	Central locking rear door Central locking, tailgate/trunk	BL-R
42	-	
43	-	
44	-	
45	-	
46	-	
47	-	
48	-	
49	-	
50	Power window lift motor, rear door	GN
51	Power window lift motor, rear door	GR
52	-	
53	Power window lift motor, rear door ON/OFF	P