

## Connector at right A-post (wheel housing harness and door sill harness)

Connector **C3** (pos. 1-25 in 53-pin)  
Instrument panel harness - right wheel  
housing harness

D24TIC

1	High beam, right	R-W
2	Low beam, right	GN-W
	Beam width control	GN-BN
3	Turn signal, right	BL-GN
4	Parking light, right	GR
5	Washer motor, tailgate	BL-Y
6	-	
7	-	
8	-	
9	-	
10	-	
11	-	
12	-	
13	Front foglights	W-SB
14	-	
15	Headlight wiper motor	Y
16	Beam width control	GR
17	Headlight wiper motor	BL-R
	Windshield washer motor	
18	-	
19	-	
20	-	
21	-	
22	-	
23	-	
24	Washer fluid level sensor	BL-W
25	-	

Connector **C3** (pos. 26-53 in 53-pin)  
Instrument panel harness - door sill harness

26	-	
27	-	
28	-	
29	Door-open warning light, right rear	GN-R
30	Door switch rear door	BN-SB
	Door switch right front door	BN-SB
31	Door switch right front door	W-SB
32	Side turn signal repeater	BL-GN
33	-	
34	-	
35	Loudspeaker, right rear door +	BL-P
36	Loudspeaker, right rear door -	BN-P
37	-	
38	Central locking, rear door	R-W
39	-	
40	-	
41	Central locking, rear door	BL-R
42	-	
43	-	
44	-	
45	-	
46	-	
47	-	
48	-	
49	-	
50	Power window lift motor, rear door	BN
51	Power window lift motor, rear door	Y
52	-	
53	Power window lift motor, rear door ON/OFF	P