


Connectors in engine compartment at left suspension tower



D24TIC

Connector C51 (8-pin)

1	Engine coolant temperature (ECT) sensor pos. 1	Y-W
2	Oil pressure sensor	SB
3	Timer relay, exhaust gas recirculation (EGR) pos. 4	BL
	Idle air control (IAC) switch, EGR	
	Fuel valve	
	Aneriod switch pos. 1	
4	Generator D+	R
5	Starter motor 50	BL-GN
6	Engine coolant temperature (ECT) sensor diesel	BN
7	Generator W	R-W
8	Engine coolant temperature (ECT) sensor pos. 2	Y-SB

Connector C117 (2-pin)

1	Pressure sensor, turbodiesel	Y-R
2	-	