


Cruise control Schematic presentation




Setting speed

Switch set to ON.
SET-button pressed in and released.
Speed above 35 km/h (20 mph) and
neither brake nor clutch pedal
pressed.

Maintaining set speed

Switch set to ON.
Speed above 35 km/h (20 mph) and
neither brake nor clutch pedal
pressed.



Increasing set speed

Switch set to ON.

The cruise control regulates
throttle setting.

If the SET-button is held pressed for more
than 0.5 seconds, the speed will slowly
increase until the SET-button is released.

If the SET-button is held pressed for less
than 0.5 seconds, the speed will increase by
1.6 km/h (1 mph).