






Connectors for doors



Connector **C143** (24-pin) at A-post passenger's side

| | | |
|----|--------------------------------------|-------|
| 1 | Warning light | GN-R |
| 2 | Warning light | W-SB |
| 3 | Loudspeaker + | GN-W |
| 4 | Loudspeaker - | BL-SB |
| 5 | Central lock, unlocking | R-W |
| 6 | Central lock, locking | BL-R |
| 7 | Heating, power door mirrors | BL-GN |
| 8 | Power door mirrors | BL-W |
| 9 | Power door mirrors | BN-W |
| 10 | - | |
| 11 | Power door mirrors | GN-W |
| 12 | - | |
| 13 | - | |
| 14 | - | |
| 15 | - | |
| 16 | - | |
| 17 | - | |
| 18 | - | |
| 19 | - | |
| 20 | - | |
| 21 | Ground connector, power door mirrors | SB |
| 22 | Window lift motor | BL |
| 23 | Window lift motor | R |
| 24 | Window lift motor, supply | Y-R |

Connector **C144** (24-pin) at A-post, driver's side

| | | |
|----|---|-------|
| 1 | Warning light | GN-R |
| 2 | Warning light | W-SB |
| 3 | Loudspeaker + | GN-W |
| 4 | Loudspeaker - | BL-SB |
| 5 | Central lock, unlocking | R-W |
| 6 | Central lock, locking | BL-R |
| 7 | Heating, power door mirrors | BL-GN |
| 8 | Power door mirrors passenger's door | BL-W |
| 9 | Power door mirrors passenger's door | BN-W |
| 10 | Power door mirrors, supply | OR |
| 11 | Power door mirrors passenger's door | GN-W |
| 12 | Ground connection, central locking | BN-SB |
| 13 | Central lock, unlocking | GN-SB |
| 14 | Central lock, locking | Y-SB |
| 15 | Window lift motor rear door pass. side | BN |
| 16 | Window lift motor rear door pass. side | Y |
| 17 | Window lift motor rear door driver's side | GN |
| 18 | Window lift motor rear door driver's side | GR |
| 19 | ON/OFF power window lift motors, rear doors | P |
| 20 | Window lift motor supply | Y-R |
| 21 | Ground connection, power window lift motors, power door mirrors | SB |
| 22 | Window lift motor passenger's door | BL |
| 23 | Window lift motor passenger's door | R |
| 24 | - | |

Connector **C149** (11-pin) at B-post, passenger's side

| | | |
|----|--------------------------|-------|
| 1 | Central lock, unlocking | R-W |
| 2 | Central lock, locking | BL-R |
| 3 | Warning light door | GN-R |
| 4 | Warning light door | BL-SB |
| 5 | Window lift motor ON/OFF | P |
| 6 | Window lift motor | GN-BN |
| 7 | Window lift motor | Y-GR |
| 8 | Loudspeaker + | BL-W |
| 9 | Loudspeaker - | BN-SB |
| 10 | - | |
| 11 | - | |

Connector **C150** (11-pin) at B-post, driver's side

| | | |
|----|--------------------------|-------|
| 1 | Central lock, unlocking | R-W |
| 2 | Central lock, locking | BL-R |
| 3 | Warning light door | GN-R |
| 4 | Warning light door | BL-SB |
| 5 | Window lift motor ON/OFF | P |
| 6 | Window lift motor | GN-BN |
| 7 | Window lift motor | Y-GR |
| 8 | Loudspeaker + | BL-W |
| 9 | Loudspeaker - | BN-SB |
| 10 | - | |
| 11 | - | |