

Alphabetical index

Anti-lock Brake System, ABS	152
Beam width control	74
Back-up (reversing) lights	84
Blower (standard heater) fan	174
Bulb failure warning light	118, 120
Car alarm cable harness	114
Central locking	156
Cigar lighter	110
Combined instrument	126
Component list (foldout)	at end of book
Control panel lights	98
Cruise control	52, 54
Diesel preheating (D24TIC)	62
Door mirrors with timer relay	162
EGR (D24 TIC)	62
Electrical circuitry	6
Electronic Climate Control (ECC)	178
Engine cooling fan FC	50
Exhaust temperature sensor (Japan)	180
Foglights	86, 88, 90
Fuses	4
Glove compartment, lighting	92
Ground connections	42
Hazard warning flashers	100
Headlight wash/wipe	104
Heated driver's/passenger's seat	166, 168
Heated rear window	160, 162
High and low beam	64, 66, 68, 70
Horn	102
Ignition switch	8
Instrument lights	98
Interior lighting	94
LH-jetronic 2.4	46, 48
License plate lights	76, 78
Location of relays	8, 9
Manual Climate Control (MCC)	176
On-board diagnostics (OBD)	112
Overdrive AW 70/71	148
Overload protector (D24 TIC)	62
Parking lights	76, 78
Power door mirrors	164
Power seat	170, 172
P-shift lock, automatic transmission	150
Power sunroof	158
Power supply	60
Power window lifts	154
Pre-routed wiring for towing hook	116
Radio connections	132, 134, 136, 138, 140, 142, 144, 146
Reduced Intensity low beam (DIM-DIP) (UK)	72
Relay location, electrical dist. unit	9
Relay location in engine compartment	8
Seat belt reminder	122, 124
SRS (Airbag)	182, 184
Starter system	60
Stop (brake) lights	76, 78
Tailgate wash/wipe	108
Tail lights	76, 78
Trunk (boot) light	96
Turn signals	100
Vanity mirror lighting	92
Windshield wash/wipe	106