

13/23 (Left wheelhousing harness)

On/Off		Color	Remarks
3/37:1	Horn switch (via connector C2:17)	BL-SB	
16/10:2	Horn 1	BL-SB	
16/11:2	Horn 2	BL-SB	

13/24 (Dashboard harness)

On/Off		Color	Remarks
3/1:50	Ignition switch	P	
3/40:50	Park/Neutral Position (PNP) Switch automatic transmission (via connector C166:6 at CEM)	P	Automatic transmission only
6/25:15	Starter motor (via connector C166:6 at CEM) connector C166:5 at CEM, connector C2:1 Dashboard harness-Left wheelhousing harness and connector C51:5 Left wheelhousing harness-Engine harness)	P	Manual transmission only Not D24TIC
17/1:1	Service socket for turning over starter motor (via connector C2:24 Left wheelhousing harness-Dashboard harness)	P	Only D24TIC engine
4/23:30	Control module LH-Jetronic 2,4 (via connector C3:5 Right wheelhousing harness-Dashboard harness)	P-W	Only B200F, B230FB/FD/G
4/23:30	Control module LH-Jetronic 2,4 (via connector C3:7 Right wheelhousing harness-Dashboard harness)	P-W	Only B200FT, B230FT/FK
4/3:2	Control module, cruise control (via connector C7:5 at steering column, connector C7:6 at steering column and connector C2:43 Dashboard harness-Left wheelhousing harness)	P	Only USA/CDN and Japan with automatic transmission