



Connector in engine compartment at left suspension tower



B230GT

1	Engine coolant temperature (ECT) sensor +	(Y-W)	C51
2	Oil pressure sensor	(SB)	
3	Ground EZK Distributor Ignition (DI) pos. 20	(BN)	
4	Generator D +	(R)	
5	Starter motor 50	(BL-GN)	
6	Throttle position (TP) switch pos. 1 for EZK CM pos. 7	(OR)	
7	Temperature sensor EZK pos. 2	(GR)	
8	ECT sensor -	(BN-GR)	

B204FT

1	Engine coolant temperature (ECT) sensor +	(Y-W)	C51
2	Oil pressure sensor	(SB)	
3	Ground EZK Distributor Ignition (DI) pos. 20	(BN)	
4	Generator D +	(R)	
5	Starter motor 50	(BL-GN)	
6	Throttle position (TP) switch pos. 1 for EZK CM pos. 7	(OR)	
7	Temperature sensor EZK pos. 2	(R-SB)	
8	Engine coolant temperature (ECT) sensor -	(BN-GR)	

1	Relay, engine cooling fan pos. B2	(BL-SB)	C50
2	Ground, power stage EZK (DI)	(SB)	
3			
4	Ballast resistor	(GR)	
5	Control module EZK (DI) pos. 8	(Y)	
6			
7			
8	Relay, engine cooling fan pos. B1	(GN-W)	

1	LH, pos. 28		C50
	EGTC, sensor pos. 1	(GR-SB)	
2	Ground, power stage EZK (DI)	(SB)	
3	Ground connector, engine signal ground	(BN)	
4	Control module TCU pos. 7 to TP sensor pos. 1	(P)	
5	Control module TCU pos. 24 to TP sensor pos. 2	(P-SB)	
6	Control module TCU pos. 8 to TP sensor pos. 3	(P-W)	
7	Control module EZ-K (DI) pos. 8	(Y)	
8	Turbo control valve pos. 1	(BL-GR)	
	EGTC-sensor pos. 3		

1	
2	
3	
4	

1	Injector cyl. 1	(GN)	C132
2	Injector cyl. 2	(GN)	
3	Injector cyl. 3	(GN)	
4	Injector cyl. 4	(GN)	
5	Turbo control valve pos. 2	(BN-GN)	
6	Control module EZ-K (DI) pos. 13 (knock sensor)	(GN)	
7	Control module EZ-K (DI) pos. 12 (knock sensor)	(SB)	
8			

D24TIC

1	Engine coolant temperature (ECT) sensor +	(Y-W)	C50
2	Oil pressure sensor	(SB)	
3	Fuel valve	(BL-GN)	
	Microswitch, Idle EGR, pos. 1	(BL-GN)	
	Timer relay EGR pos. A4 (Austria)	(BL-GN)	
4	Generator D+	(R)	
5	Starter motor 50	(BL-GN)	
6	Temperature sensor	(BN-SB)	
7	Generator W	(R-W)	
8	Engine coolant temperature (ECT) sensor -	(BN-GR)	

1	Control module TCU pos. 11	(BL-SB)	C71
2	Solenoid coupling A/C	(GN-R)	
3	Blocking relay /AC pos. 4	(GN-SB)	

1	
2	
3	
4	
5	
6	
7	
8	

1		C71
2	Pressure sensor pos. 1	(Y-R)
3	A/C-compressor pos. 2	(GN-Y)