

## Alphabetical index

ABS brake system .....	140, 142
Backup (reversing) lights .....	78, 80
Beam width control .....	68
Brake lights .....	74, 76
Bulb malfunction indicator .....	114
Bulb malfunction indicator with brake monitor .....	116
Central locking .....	146
Cigar lighter .....	104
Combined instrument .....	122, 124
Connectors .....	10
Control illumination .....	84
Cruise control .....	38, 40, 42
Cruise control, function (schematic presentation) .....	42
Diesel, preheating, overload protector, EGR .....	56, 58, 60
Distributor ignition (DI) system EZ116K .....	46, 48
Electronic climate control, ECC .....	158, 160, 162
Electronically controlled automatic transmission AW30-40/43 .....	136
Engine cooling fan .....	32, 34, 36
Feedback .....	172
Fog lights .....	86, 88, 90
Fuses .....	4
Ground connections .....	20
Headlight wash/wipe .....	102
Heated driver's / passenger's seat .....	152
Heated rear window and door mirrors with timer relay .....	148
High and low beam .....	62, 64
Horn .....	96
How to use the wiring diagrams .....	2
Ignition lock .....	5
Interior, trunk and door-open warning lights .....	82
LH-jetronic multiport fuel injection system (MFI) 2.4 .....	26, 28
Motronic multiport fuel injection system (MFI) .....	22, 24
On-board diagnosis (OBD) .....	106
Overdrive .....	130, 132, 134
P-shift lock, automatic transmission .....	138
Parking lights, tail lights and number plate lights .....	70, 72
Power door mirrors .....	150
Power window lifts .....	144
Power seat .....	154, 156
Power sunroof .....	164
Power supply .....	50
Pre-routed wiring for ambient temperature gauge .....	112
Pre-routed wiring for anti-theft alarm .....	108
Pre-routed wiring for towing hook .....	110
Radio connections .....	126, 128
Reduced intensity low beam (DIM-DIP), Great Britain .....	66
Relay box .....	5
Relay location in engine compartment .....	8
Seat belt reminder .....	118, 120
SRS Supplemental Restraint System (airbag) .....	168, 170
Starter system .....	52, 54
Tailgate wash/wipe .....	100
Temperature sensor, Japan .....	166
Turbo control system, TCU (B204FT) .....	30
Turn signals and hazard warning flashers .....	92, 94
Windshield wash/wipe .....	98
Wiring harnesses .....	6