




Ground connections




Ground connection,
battery-body





Ground connection,
battery-engine




Right tail light unit
(5-door)



Left tail light unit
(5-door)
Number plate lights
Bulb malfunction indicator,
rear
Tailgate wiper
Trunk light
Heated rear window
High level brake light
Power antenna




31/1




Right headlight
Right turn signal indicator
Right parking light
Washer motor
Washerfluid level sensor
Right foglight (auxiliary light)
Heated oxygen sensor (HO2S)
Relay, radio interference suppression
Engine cooling fan
Idle air control
Right headlight wiper motor
Hydraulic unit ABS (B6304F/G)
Auxiliary lights
Pressure sensor relays, engine
cooling fan (not B204FT)
Engine coolant level (EC) sensor
(B204FT and B6304F/G)
Vehicle speed (VSS) sensor (D24TIC)

31/2



Left headlight
Left turn signal indicator
Left parking light
Left headlight wiper motor
Auxiliary light
Relay radio interference suppression
Washer motor
Washer level sensor
Left foglight (auxiliary light)
Engine cooling fan
Cruise control
Relay, glow plug system
Hydraulic unit, ABS
Brake fluid level sensor
Test socket A (diagnosis OBD)

31/6



Left side turn signal repeater
Power windows
Central locking
Power mirrors
Instruments
ABS
Heated door mirror, left side
Transmission control module
Kickdown switch AW30-43
Vanity mirror light, left side
Cruise control