



Power supply



Live connections in different positions of ignition switch 3/1

Pos.	Socket					
	30	X	15	15I	50	S
K0	X					
0	X	X	X	X	X	X
I	X	X	X	X	X	X
II	X	X	X	X	X	X
III	X	X	X	X	X	X

Ignition on
(engine not running)



Generator charging

