Radio connections, 5-door

*) Connector in radio compartment, 1-pin
**) Connector at power antenna, 4-pin (junction)